Retrofit Kit Lay-in Troffer

Approvals



Certification

UL listed

Illumination solution

The main diffuser and slanted troffer help reduce glare and create a pleasant, uniform throw of the light in existing recessed troffer without the need to enter the ceiling space.

Dimming

With standard 0-10V dimming driver provided, Retrofit kit maintains higher percent of the light in a 120-degree beam angle to project light downward towards surfaces.

Simplicity

Ingenious structural design can reduce the difficulties of installation and maintenance. A sleek, contemporary appearance is designed to enhance office, healthcare, retail and education interiors.

Warranty: 5 years Rated Life: 50,000hrs











Healthcare

Factory

Education

Office


Retail



1. Features

- Topband Retrofit Kit LED Troffer is an ideal illumination solution to upgrade fluorescent troffer to LED, energy saving and without need to actually break the ceiling plenum.
- Compatible with both standard and narrow T-grids, they offer a simple retrofit that will improve the ceiling look.
- Both the 2`*2` and the 2`*4` retrofit kit troffer are manufactured with quality components and finishes, meaning a consistent, balanced lighting scheme.
- External isolated power supply takes heat sensitive components away from the heat source.
- When fluorescent fixtures can buzz and flicker and contribute to headache and eye fatigue, Retrofit kit
 is constructed with LM-80-rated LEDs and a smooth frosted PC diffuser, making it the silent and
 flicker-free solution for offices, factory, lobbies, hallways and conference rooms in schools, healthcare
 facilities, showrooms, factory, retailers and more.

2. Product Dimensions



Item	L(mm)	W(mm)	H(mm)	
2*2FT	607+/-1.5	607+/-1.5	67+/-1.5	
2*4FT	1213+/-1.5	607+/-1.5	67+/-1.5	



Product Specification Electrical Characteristics

• Humidity • Temperature Input Voltage: AC100-277V 50/60Hz

Operating10%-80% Operating -20~+40 ℃ PF:>0.9, THD<20%, CRI>80


Storage 10%-80% Storage -20~+40 ℃ Power efficiency: 87%

Premium Efficacy - Retrofit Kit LED Troffer

Item	Wattage/ Size	LED Q'TY	ССТ	Efficacy	Beam Angle	Cover	Dimmable
			3500K	126LM/W			
TPRKPD22DLB-	30W 2*2FT	240pcs 2835LEDs	4000K 4500K	130LM/W	140°	Frosted	0-10V
30WB(XXP)	2 2 5 1	2033LEDS	5000K	130 LM/W			
			3500K	125 LM/W			
TPRKPD22DLB- 40WB(XXP)	40W 2*2FT	288pcs 2835LEDs	4000K 4500K	130 LM/W	140°	Frosted	0-10V
			5000K	130 LM/W			
			3500K	129 LM/W			
TPRKPD24DLB- 40WB(XXP)	40W 2*4FT	384pcs 2835LEDs	4000K 4500K	130 LM/W	140°	Frosted	0-10V
			5000K	130 LM/W			
			3500K	130 LM/W			
TPRKPD24DLB- 50WB(XXP)	50W 2*4FT	420pcs 2835LEDs	4000K 4500K	130 LM/W	140°	Frosted	0-10V
			5000K	130 LM/W			

4. Installation Guide


4.1 Components and Tools required




C. Closing panel(*1)

A. Side panel(*2)


4.2 Installation steps




Step1. Turn power off and take out original cover and tubes.




Step2. Remove all the parts such as lamp holder, starter etc. Cut off power wire as shown in ①. If the distance between ballast and ceiling surface is lesser than 3 inch, cut wire ② and remove ballast.



Step3. Fix the supplied fasteners (6 pcs in all) to LED panel (B) and closing panel (C) separately and pay attention to the directions.




Step4. Install side panel (A) in between troffer.



Step5. Connect LED panel (B)'s DC 0-10V dimmable wire, ground wire and AC input wire well. Drill two 4.2mm dim holes in the original bottom troffer by tools. Fixate the safety cable to the bottom troffer by screw.


- * For the dimmable wire:
- 1) If there is unnecessary to dim, no need to connect dimmable wire and the connector can't be removed.
- 2) If there is necessary to dim, connect dimmable wire to Vdc and the dimmable wire should be rated 300V.
- *AC input wire connect with part①or②based on situations.



Situation1: Screw grounding cable from LED panel (B) to original troffer if host fixture ground connection is made through host fixture.

Situation2: Connect to the incoming ground lead from conduit.


Turn fastener 90 degrees clockwise or anti-clockwise



Step6. Install LED panel (B) in between troffer, making sure the tabs at each corner of the LED panel slide into the respective slots on the side panel. Install closing panel (C) in between troffer. Fixate panels and establish ground by turning fastener 90 degrees.

Warning: RISK OF FIRE OR ELECTRIC SHOCK

While installing LED panel (B) and Closing panel (C), make sure the electrical wiring is not clamped between panels.



Step7. Press Diffuser (D) inward and make sure fix well. Turn power on. This retrofit kit is on. The installation is finished.

5. Package

Item	Net Weight	Gross Weight	Carton Dimensions	
2FT*2FT	3.32 kg	4.56kg	650*486*90mm	
2FT*4FT	5.72kg	7.50kg	1220*486*90mm	

Notice: The Retrofit Kit LED Troffer is packaged in bulk.